




INSTALLING


your freestanding bathtub

EN



2. LEVELLING

Use the adjustable feet to level the bathtub.
The bathtub should be resting on its feet, not on its apron.
Leave a gap of 5 mm between the tub and the floor.




4. DRAINAGE TEST

Run the water to test for proper drainage. If necessary, adjust the levelling feet. Before going any further, double check that all plumbing connections are secure and that there are no leaks.

1. PLACEMENT

Remove the bathtub from its packaging. Always be sure to place the bathtub on a mat or piece of cardboard to avoid damaging it. Determine and mark the bathtub's placement and drain location.



3. CONNECTIONS

Connect the drain (not provided) to the trap and double check that your plumbing connections are watertight.



5. SEALANT

Apply silicone sealant (not provided) along the seam between the tub and the floor. Let the sealant dry for 24 hours before using the bathtub.